

MODULE 3

HOW TO USE PREVAIL™ PRODUCTS

A one-step solution to simplify your daily cleaning and disinfection tasks

START

HOW TO USE PREVAIL™ PRODUCTS

Scrub-a-dub-dub...

If you take a moment to think about it, you do a lot of cleaning and disinfecting every day in your facility. Like, a lot.

You might have many cleaning and disinfectant products floating around, making it hard to manage inventory and to choose a suitable product for a particular task.

CAN WE MAKE THIS EASIER?

Click on the blue buttons throughout the module to learn more!

YES!

Consider an ALL-IN-ONE SOLUTION.

HOW TO USE PREVAIL™ PRODUCTS

Prevail™

Your ALL-IN-ONE **CLEANING** and **DISINFECTING** Solution.

We learned about the 7 Steps to Good Infection Prevention and what makes a disinfectant effective for the animal health setting.

Now, let's take a closer look at how the **Prevail™** family of products can streamline and simplify the daily cleaning and disinfection tasks at your facility!

HOW TO USE PREVAIL™ PRODUCTS

The All-In-One Family

The family of **Prevail™** disinfectants -all powered by **Accelerated Hydrogen Peroxide®** - provides flexible options to suit the needs of your facility.

Team Concentrate Strategic and Calculated

Click on the round buttons throughout the module to learn more!

Concentrate

Set your own dilution to suit your specific cleaning and disinfection task.

Team Ready-to-Use

Ready to get to it!

Ready-to-Use (RTU) Liquids and Wipes

Convenient formats that require no dilution or mixing.

HOW TO USE PREVAIL™ PRODUCTS

Don't be a Disinfection Delinquent!

Proper disinfection requires following the product label instructions. Let's meet some common misuse culprits.

HOW TO USE PREVAIL™ PRODUCTS

Disinfection Delinquent #1

The "GUESSTIMATOR"

Difficulty concentrating ... on concentration.

VIOLATIONS

- Eyeballing dilution mixtures
- Topping off diluted disinfectant bottles

CORRECTIVE ACTION

Stop the guessing and follow these two rules:

Click on each button to learn more!

RULE 1

ALWAYS MEASURE WHEN DILUTING

Incorrect measurements or using less disinfectant in an attempt to save money can lead to a weak, ineffective disinfectant solution.

RULE 2

USE A CLEAN AND DRY EMPTY BOTTLE FOR DILUTING SOLUTION

Mixing old and new disinfectant can lead to an over diluted, inactive mixture, which may be less effective.

Don't forget to label your bottle to meet OSHA requirements!

HOW TO USE PREVAIL™ PRODUCTS

Tips on using Prevail™ Concentrate

TOOLS

Take away the guesswork, for a dependable dilution. Use dilution systems, pumps and measuring cups to achieve the correct dilution.

AHP1750 Indicator Strips

Verify the dilution of your Prevail™ Concentrate disinfectant solution.

CONTACT TIMES

Tough on hard-to-kill germs in half the time of competitive chemistries.

1:40 @ 5 minutes

(25mL Concentrate per 1L Water)

Bactericidal, Fungicidal, Virucidal*, Tuberculocidal

*Refer to the reference sheet for additional claims and use instructions.

HOW TO USE PREVAIL™ PRODUCTS

Disinfection Delinquent #2 The “COMPULSIVE DRYER”

Unable to let things dry on their own.

VIOLATIONS

- Wiping a surface dry too soon after applying the disinfectant

CORRECTIVE ACTION

HOW TO USE PREVAIL™ PRODUCTS

Disinfection Delinquent #2 The “COMPULSIVE DRYER”

Put down that towel and follow these rules:

RULE 1

TO DISINFECT, YOU CAN'T IGNORE CONTACT TIMES.

Remember, disinfectants need to remain **WET** on a surface for the appropriate contact time to be effective.

WET for entire contact time

RULE 2

YOU HAVE CHOICES! FIND A SOLUTION THAT WORKS.

For surfaces that you need to disinfect in a hurry (e.g., exam tables), make sure to use a disinfectant with a short contact time.

HOW TO USE PREVAIL™ PRODUCTS

Using Prevail™ RTU

Ready-to-Use Liquids and Wipes

Ready-to-Use Liquids

1 minute

- Bactericidal
- Fungicidal
- Tuberculocidal
- Virucidal

Ready-to-Wipes

1 minute

- Bactericidal
- Fungicidal
- Tuberculocidal
- Virucidal

HOW TO USE PREVAIL™ PRODUCTS

The One for the Job?

While all Prevail™ products are compatible with hard, non-porous surfaces, here's a guide to help you choose an optimal option for your cleaning and disinfection tasks.

Small and delicate jobs

Prevail™ Wipes

Ideal for delicate or electronic devices and equipment (or if you need to disinfect something quickly!)

- Keyboards
- Computer mice
- Office phones
- Exam tables
- Stethoscopes
- Non-critical medical equipment
- Doorknobs and handles

- Light switches
- Pens and clipboards
- Point-of-sale terminal

Medium sized jobs

Prevail™ Wipes or Prevail™ Ready-to-Use (RTU)

Ideal for most devices, equipment and surfaces.

- Grooming tools
- Leashes
- Stethoscopes
- Exam tables
- Desks
- Non-critical medical equipment
- Food and water bowls
- Surgical suites
- Small animal housing

Large jobs

Prevail™ Concentrate

Ideal for large tasks.

- Floors
- Kennels
- Surgical suites
- Transportation vehicles
- Play areas
- Runs

HOW TO USE PREVAIL™ PRODUCTS

A Quick Review

Let's take a quick look at what we've learned in this series to make sure you're ready to become your facility's...

Veterinary Infection Preventionist

WHY IS PREVAIL™ THE BETTER CHOICE FOR YOUR ANIMAL HEALTH FACILITY?

HOW TO USE PREVAIL™ PRODUCTS

A Quick Review

Prevail™ is powered by Accelerated Hydrogen Peroxide® (AHP®) which is formulated with these five key benefits in mind:

Click on each button to learn more!

FASTER

Prevail™ has: 1-5 minute contact time

CLEANER

Prevail™ has: Good activity in moderate organic debris

SUSTAINABLE

Prevail™ is: Biodegradable

COMPATIBLE

Prevail™ is: Non-corrosive and safe for use on most hard non-porous surfaces and equipment

SAFER

Prevail™ is: Non-irritating to eyes and skin, and has no harsh chemical smell

HOW TO USE PREVAIL™ PRODUCTS

Making a “Sniff-erence”

Strongly-scented products such as bleach can increase fear, anxiety and stress in patients. Using odour-neutral products like Prevail™ provide a more pleasant experience

“We believe bet visits should be Fear Free™

HOW TO USE PREVAIL™ PRODUCTS

A Deliberately Different

option for the animal health industry

Some manufacturers will “stack” their labels with easy-to-kill pathogens, or with species/strains that are not relevant to the animal health setting.

At Virox®, we pride ourselves on testing our AHP® products against the hard-to-kill and relevant pathogens within your facility.

HOW TO USE PREVAIL™ PRODUCTS

Wait! There’s more!

After you’ve completed the course, visit: www.PrevailDisinfectants.ca to build your own infection prevention program, complete with protocols for your facility.

MODULE 3

HOW TO USE PREVAIL™ PRODUCTS

REGISTER or SIGN-IN to take the quiz and complete this module.

When you have completed all three modules and quizzes, you will be able to print your Veterinary Infection Preventionist certificate!